OPERATION GUIDE

Please read the instructions carefully before using this product. This product is not allowed the user under the age of 18

Before wearing

Please use a cotton swab to clean the ear canal before wearing. If the cerumen is too much, it will block the sound outlet of the product and cause no sound.

Product parameters

Maximum saturation OSPL90 (db): 110±5dB

Full gear gain (mean HF): 38±5dB

Frequency response range: not narrower than 200Hz-8000Hz

Total harmonic distortion: ⩽3%±3%

Equivalent input noise: ⩽13±5db

How to wear

1. Choose earplugs that fit your ear canal

2. Install the selected earplugs

3. As shown in the picture, turn on and use after wearing it correctly

4. Adjust the appropriate volume

Note: Be sure to choose earplugs that fit your ear canal and wear them correctly to fit your ears as much as possible. If you don't wear it properly, there will be echoes (whistles/sounds).

Note: After wearing, you can turn on the hearing aid to adjust the volume and program! ! !

Problems encountered in wearing

1. There is no sound when wearing?

If there is no sound:

①Check whether the volume program is adjusted to suit your hearing

②Check whether the hearing aid has electricity

③Whether there is no episode in the ear canal, and the earwax is blocking the sound of the hearing aid.

Note: If the hearing aid is silent or the sound becomes low due to the blockage of the sound outlet, please clean the sound outlet.

2. Why is there a howling (sharp sound)?

Howling (sharp sound) is a manifestation of the normal working of hearing aids. The hearing aid and the ear canal are not completely matched, causing the sound from the receiver to be received by the microphone again, and the sound forms a loop, which will be continuously amplified and produce howling.

Solution: The product is equipped with earplugs of different sizes, please choose the earplugs that fit your ear canal

Turn ON/OFF

After wearing, turn it on to prevent howling/acoustic echo during wearing.

Turn the power switch to OFF to turn down.

Volume control

Roll the wheel up to increase the volume and down to decrease it.

lower the volume

Increase the volume

Mode switch

A. Hearing aid prompt: 'beep' to enter the normal mode ;

B. Hearing aid prompts twice: 'beep' to enter indoor mode

C. The hearing aid prompts three times: 'beep' to enter the outdoor mode;

Degree adjustment

After wearing in the adjustment program mode

There are 3 modes, "M" key can select different modes

Each time you press "M", a beep will remind you that you have entered the mode.

Note: The program can only be performed after the hearing aid is worn

Charging

Charging

L/R light on=hearing aid are charging

Number flashing= charging compartment is charging

Fully charged

L/R light off= hearing aid are fully charged

Number always on=charging compartment is fully charged

Hearing aids can be used for 28 hours at a time

The charging compartment can charge a single hearing aid 4-5 times

Charging

Charging completed

Charging

1. When charging the hearing aid, it can be charged through the power adapter or through the USB interface

2. Hearing aid charging: first turn off the power of the hearing aid, and then charge it. The first charge should ensure sufficient charging time (not affected by the indicator light), and a charging time of 5–6 hours should be guaranteed

3. If the hearing aid is not used for a long time, the battery self-discharge will cause the battery to be seriously insufficient. It should be charged, and the charging time should reach 5–6 hours. Even if the charging indicator shows that the charging is complete, the charging should not be stopped (guarantee to reach 5–6 hours)

Charging

4. During use, the hearing aid volume becomes low or when the hearing aid is not in use, the power should be turned off and charged (this will better protect the hearing aid battery). This is very important! Otherwise it will cause excessive discharge

5. The hazards of excessive battery discharge

Will reduce the battery capacity and affect the battery life to varying degrees

6. When using AC power to charge, if the charging is over, unplug the power in time

21-day wear chart

THE JOURNEY TO LISTENING

Unlike vision correction, which simply wears glasses, hearing correction is a rather detailed process. Once you start your hearing correction journey, you will experience countless "new sounds", and your brain needs to adapt for a period of time. In just a few weeks, you will be shocked by the sound that you have never experienced before.

If you have any questions, we will serve you wholeheartedly.

THE FIRST WEEK

Some sounds may be too noisy when wearing a hearing aid for the first time, such as the buzzing of the refrigerator, the wrinkling of paper, or the sound of your footsteps. This is normal, and your brain is relearning how to prioritize these sounds that you don't hear very often. Sometimes you may not like the noise, but please don't give up wearing. Please don't give up wearing them!

Patient

At the beginning, wear the hearing aid for 30 minutes a day, and then gradually increase the wearing time until the whole day.

Exercise

Listen carefully to a song you are familiar with or watch a TV game show, and guess the answer without looking at the subtitles.

THE SECOND WEEK

The more you wear the hearing aid, the more you can adapt to the sound environment. You even can ask people around you not to speak loudly to you anymore,because you can easily communicate with people.

THE THIRD WEEK

After a few weeks, you will feel more energetic because you no longer need to spend a lot of energy to listen what others say. The sound will become clearer and clearer, and you will once again enjoy the sounds that surround in your life, such as the melodious singing of birds in the backyard, the cheerful laughter of children, and the rustling of leaves in the wind.

Participate

Have a meal in a restaurant with friends, watch a movie in a theater, join a family gathering, and no longer have to bother to speculate about missed information.